
OneOdio

STUDIO

Wireless C Y80B



OneOdio

Thank you for choosing **OneOdio** Studio Wireless (Y80B). Please read this manual carefully before use.

Specifications


Model Name:	Studio Wireless (Y80B)	Diameter of Diver Unit:	φ50mm
Impedance:	32 Ω	Frequency Response:	20Hz-20KHz
Battery Capacity:	500mAh	Speaker Driver Magnet:	Neodymium
Sensitivity:	110±3dB	Charging Time:	≈3 hours
Audio Output:	Wireless/Wired	Standby Time:	⩾500 hours
Transmission Range:	Up to 33 feet / 10 meters	Playing Time:	⩾30 hours

Accessories

3.5mm Audio Cable with In-Line Mic	Micro USB Charging Cable
Packing Bag	User Manual


Features


1. Wireless & Wired: 3-hours charging time brings you 30-hours playtime experience in Bluetooth mode. A built-in 500mAh battery makes it possible for you to immerse yourself in a noiseless music world up to 30 hours. Moreover, it can be used as a wired headphone by the attached audio cable when it runs out of batteries.
2. Universal Compatibility: The Bluetooth V5.0 headphone provides a wireless range up to 33ft (10m), and it is compatible with all devices that can connect to Bluetooth or 3.5mm plug cable.
3. Special Ergonomic Design: The middle button is lower than the buttons of the two sides, which makes it easy for button identification. Equipped with a high/low switch button to control the volume of calls and music. The memory-protein ear cushion simulates the texture of human skin, ensuring long-time wearing.
4. Excellent Auditory Experience: The 50mm large neodymium driver and innovative technology deliver high definition sound in new perfection, and reproduces all your music dynamics and controlled bass that audiophiles need. Bring you a more immersive experience.



5. Secure Connection-Damping Socket: To ensure the audio cable been locked in place and stay a secure connection, we add a jack lock on the 3.5 mm stereo Aux cable. You need not worry about the audio cable being easily pulled out of the headset. It well helps avoid poor contact or loose jack.

Instruction





❶ Micro USB charging port	❷ Volume up/ Next track — Short press / Long press
❸ Multiple button — On/Off; Play; Pause; Call/Answer/Hang up	❹ Volume down/ Previous track — Short press / Long press
❺ LED indicator	❻ 3.5mm aux-in jack
❼ Built-in Mic	❽ 3.5mm Audio Cable with In-Line Mic
❾ Micro USB Charging Cable	

Charging

- Connect the headphones to a PC or power adapter with the USB charging cable.
- The LED indicator will turn into red whilst charging and will turn blue when it is fully charged. The first charge may take up to more than 3 hours to complete.

Note: Please notice that the charging voltage must not exceed 5V.

Pairing a Wireless Device

1. Keep the headphones and the mobile phone/music player within 1 meter of each other when pairing.
2. Enter pairing mode directly after turn on the headphones.
3. Turn your iOS, Android or Windows device's Bluetooth on and select "Studio Wireless" from the list of found devices.
4. If asked for a passcode, please enter"0000"and the headphones will be connected to your device.
5. After pairing successfully, the LED light will flash blue occasionally, you can then answer the phone or listen to your music.

Note: If there is NO STEREO SOUND(like old radio sound) from some of your apps in your PC due to the Bluetooth technology limitations, please try to use them in the WIRED MODE. If you have any sound issue with Studio Wireless when you pair them with your PC(especially Windows 10)or other devices, please contact us by mail **info@oneodio.com**.

Multi Point

The wireless Bluetooth headset connects two devices at the same time. Follow the steps in "Pairing", then turn off the Bluetooth on the connected device and repeat the steps with the second device. After successfully connecting the second device, turn on Bluetooth on the first. Both devices will now be connected to the headset. Solved the problem of music shuttering in the first 20 seconds. If you turn off and restart the headphones, only one device will be reconnected to it automatically. You should connect the other device manually.

Playing Music

1. Adjusting the volume: Short press "+" or "-" for volume up or volume down. The volume is completely synchronized with iphone and most Android devices. The last two gears skip at a time.
2. Music Selection: Long press "-" or "+" for previous track or next track.
3. Play/Pause: Press (don't hold) Play/Pause to switch between play and pause status.

   Note: The controls will not function when charging.

Call-handling


Press the Play/Pause ③ once to answer/end the call. During the call, you can adjust the volume by using the volume + ② and volume – ④ buttons on the headphones.

Siri and Clear Up Memory

For Siri, long press ③ and hold for one or two seconds until you hear a "Di" prompt tone. Let go once you hear prompt tone, otherwise the headphones will be turned off.
Clear the paired device memory, please press the volume button ② ④ at the same time.

Turn to Wired Mode

❶ Ensure the headphones are switched off during wired use
❷ Connect the 3.5mm cable into the 3.5mm aux-in jack
❸ Connect the other end of the 3.5mm cable into your device
Note: Inserting 3.5mm cable disables wireless




Power On

Press and hold the On/Off button ③ to turn the headphones on. The LED light will flash between blue and red when the headphones are active.


Power Off

Press and hold the On/Off button ③ to turn the headphones off. The LED indicator turns off, indicating that the headphones are off.


How to Rotate (Maximum swivel angle:90°)



How to Fold the Headphones



How to Adjust the Headband



Limited Warranty

Please sign up for OneOdio warranty service at **www.oneodio.com.**

OneOdio warrants that this product, for a period of 2 years from the date of retail purchase by the original end-use purchaser, when delivered to you in new condition, in original package, from an OneOdio authorized reseller and used in normal conditions, is free from any defects in manufacturing and workmanship. We will, at our sole option, repair or replace (using new or refurbished replacement parts) any defective parts within a reasonable period of time and free of charge.

24/7 Customer Service | Telephone: **00852 6940 3848**, Email: **info@oneodio.com**

What is not Covered

This warranty does not cover defects resulting from improper or unreasonable use or maintenance; failure to follow operating instructions; accidents; excess moistures; insects; lightning; unauthorized alteration or modification of original condition; damage caused by inadequate packing or shipping procedures; loss of, damage to or corruption of stored data; damage caused by use with non-OneOdio products; product that requires modification or adaptation to enable it to operate in any country other than the country for which it was designed, manufactured, approved and/or authorized, or repair of products damaged by there modifications; and products purchase form unauthorized dealers.

How to Make a Claim

In the event damage has occurred to products, you must follow these instructions:

- Within two months, contact **info@oneodio.com** with order number in e-commerce website after you discover a product defect (or should have discovered it, if such product defect was obvious);
- In order to get professional solutions of OneOdio, please give a detailed explanation of how the damage occurred.
- Return the products. OneOdio will, at our sole option, repair or replace (using new or refurbished replacement parts) any defective parts within a reasonable period of time and free of charge.

Other Legal Rights

This limited warranty gives you specific legal rights, and you also may have other rights that vary from state to state or country to country. Some places do not allow limitations on implied warranties or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

FAQ

❶ If there is NO STEREO SOUND(like old radio sound) from some of your apps in your PC due to the Bluetooth technology limitations, please try to use them in the WIRED MODE.

❷ These headphones are passive noise isolating, not active noise cancellation (ANC), it can't cancel the noise completely but it won't drain the battery and damage the sound.

❸ If you cannot connect the headphones to your device, please try the followings:

- 1. Ensure that the headphones are charged, switched on, paired with and connected to your device.
- 2. Check the headphones are within 10 meters (33 feet) of your device and there are no obstructions (such as walls or other electronic devices) between the headphones and the devices.
- 3. If you receive an intermittent signal, please ensure the headphones are fully charged before continuing use.
- 4. If you don't use the headphones for longer than 10 minutes whilst no connected to a device, they will automatically power off to conserve power.